

Le Café




30GCC035C COFFEEPOT KAFFEEKANNE CAFETIERE CAFETERA КОФЕЙНИК KONVICE KÁV. S VÍKEM Ø 85 mm • 3 1/8 in c. 350 ml • 11 3/8 oz h. 140 mm • 5 1/2 in l. – w. – h./11 pc – wt. 0,25 kg • 0,55 lb. pck. 3 pc • pal. 270 pc 8592404116828	30GC0474C CREAMER GIEßER CREMIER LECHERA МОЛОЧНИК MLEKOVKA Ø 70 mm • 2 9/16 in c. 250 ml • 8 3/8 oz h. 95 mm • 3 3/8 in l. – w. – h./11 pc – wt. 0,154 kg • 0,34 lb. pck. 6 pc • pal. 672 pc 8592404102517	30GC0467C CREAMER GIEßER CREMIER LECHERA МОЛОЧНИК MLEKOVKA Ø 55 mm • 2 1/8 in c. 180 ml • 6 oz h. 90 mm • 3 3/8 in l. – w. – h./11 pc – wt. 0,13 kg • 0,29 lb. pck. 6 pc • pal. 672 pc 8592404103415	30GCHB18C SUGAR BOWL ZUCKERDOSE SUCRIER AZUCARERO САХАРНИЦА SUKRENKA S VÍKEM Ø 100 mm • 3 1/8 in c. 180 ml • 6 oz h. 85 mm • 3 3/8 in l. – w. – h./11 pc – wt. 0,161 kg • 0,36 lb. pck. 6 pc • pal. 720 pc 8592404102395
--	--	--	--

Capri



30GC0160C CUP TASSE TASSE TAZA ЧАШКА SALEK Ø 64 mm • 2 1/2 in c. 80 ml • 2 3/4 oz h. 52 mm • 2 in l. – w. – h./11 pc – wt. 0,105 kg • 0,23 lb. pck. 6 pc • pal. 2112 pc 8590992880695	30GC0147C CUP TASSE TASSE TAZA ЧАШКА SALEK Ø 58 mm • 2 1/4 in c. 100 ml • 3 3/8 oz h. 72 mm • 2 7/8 in l. – w. – h./11 pc – wt. 0,13 kg • 0,29 lb. pck. 6 pc • pal. 1620 pc 8590992880756	30GC0165C CUP TASSE TASSE TAZA ЧАШКА SALEK Ø 79 mm • 3 1/8 in c. 160 ml • 5 1/2 oz h. 64 mm • 2 1/2 in l. – w. – h./11 pc – wt. 0,18 kg • 0,4 lb. pck. 6 pc • pal. 1056 pc 8590992880817	30GC0169C CUP TASSE TASSE TAZA ЧАШКА SALEK Ø 94 mm • 3 9/16 in c. 240 ml • 8 oz h. 65 mm • 2 1/2 in l. – w. – h./11 pc – wt. 0,23 kg • 0,51 lb. pck. 6 pc • pal. 936 pc 8590992880879
---	---	--	---

Elba



30GE0160E CUP TASSE TASSE TAZA ЧАШКА SALEK Ø 64 mm • 2 1/2 in c. 80 ml • 2 3/4 oz h. 52 mm • 2 in l. – w. – h./11 pc – wt. 0,105 kg • 0,23 lb. pck. 6 pc • pal. 2112 pc 8590992881173	30GE0147E CUP TASSE TASSE TAZA ЧАШКА SALEK Ø 58 mm • 2 1/4 in c. 100 ml • 3 3/8 oz h. 72 mm • 2 7/8 in l. – w. – h./11 pc – wt. 0,13 kg • 0,29 lb. pck. 6 pc • pal. 1620 pc 8590992881234	30GE0165E CUP TASSE TASSE TAZA ЧАШКА SALEK Ø 79 mm • 3 1/8 in c. 160 ml • 5 1/2 oz h. 64 mm • 2 1/2 in l. – w. – h./11 pc – wt. 0,18 kg • 0,4 lb. pck. 6 pc • pal. 1056 pc 8590992881296	30GE0169E CUP TASSE TASSE TAZA ЧАШКА SALEK Ø 94 mm • 3 9/16 in c. 240 ml • 8 oz h. 65 mm • 2 1/2 in l. – w. – h./11 pc – wt. 0,23 kg • 0,51 lb. pck. 6 pc • pal. 936 pc 8590992881357
---	---	--	---

Ischia



30GI1220I CUP TASSE TASSE TAZA ЧАШКА SALEK Ø 64 mm • 2 1/2 in c. 80 ml • 2 3/4 oz h. 52 mm • 2 in l. – w. – h./11 pc – wt. 0,105 kg • 0,23 lb. pck. 6 pc • pal. 2112 pc 8590992892117	30GI1228I CUP TASSE TASSE TAZA ЧАШКА SALEK Ø 58 mm • 2 1/4 in c. 100 ml • 3 3/8 oz h. 72 mm • 2 7/8 in l. – w. – h./11 pc – wt. 0,13 kg • 0,29 lb. pck. 6 pc • pal. 1620 pc 8590992892155	30GI1223I CUP TASSE TASSE TAZA ЧАШКА SALEK Ø 79 mm • 3 1/8 in c. 160 ml • 5 1/2 oz h. 64 mm • 2 1/2 in l. – w. – h./11 pc – wt. 0,18 kg • 0,4 lb. pck. 6 pc • pal. 1056 pc 85909928921531	30GI1222I CUP TASSE TASSE TAZA ЧАШКА SALEK Ø 94 mm • 3 9/16 in c. 240 ml • 8 oz h. 65 mm • 2 1/2 in l. – w. – h./11 pc – wt. 0,23 kg • 0,51 lb. pck. 6 pc • pal. 936 pc 85909928921593
---	---	---	--

T



30GCC055C TEAPOT TEEKANNE THEIERE TETERA CON TAPA ЧАЙНИК KONVICE ČAJ. S VÍKEM Ø 120 mm • 4 3/8 in c. 550 ml • 18 3/8 oz h. 130 mm • 5 1/8 in l. – w. – h./11 pc – wt. 0,379 kg • 0,84 lb. pck. 3 pc • pal. 204 pc 8592404103477	30GC0168C CUP TASSE TASSE TAZA ЧАШКА ŠALEK NÍZKY Ø 105 mm • 4 1/8 in c. 260 ml • 8 3/8 oz h. 55 mm • 2 1/8 in l. – w. – h./11 pc – wt. 0,17 kg • 0,38 lb. pck. 6 pc • pal. 840 pc 8592404151553	30GC0234C SAUCER COMBO UNTERTASSE COMBI SOUCOUCPE COMBI PLATILLO COMBI БЛЮДЦЕ ЦОМБИ PODŠALEK COMBI Ø 155 mm • 6 1/8 in c. – h. 19 mm • 3/8 in l. – w. – h./11 pc 145 mm • 5 9/16 in wt. 0,25 kg • 0,55 lb. pck. 6 pc • pal. 2058 pc 8590992845977	30GC1440C MUG WITHOUT HANDLE BECHER GOBELET BOTE КРУЖКА POHÁREK Ø 75 mm • 3 in c. 260 ml • 8 3/8 oz h. 90 mm • 3 1/2 in l. – w. – h./11 pc – wt. 0,281 kg • 0,69 lb. pck. 6 pc • pal. 912 pc 8592404151492
---	---	---	--



30GC0263C CUP TASSE TASSE TAZA ЧАШКА ŠALEK Ø 110 mm • 4 3/8 in c. 350 ml • 11 3/8 oz h. 71 mm • 2 3/4 in l. – w. – h./11 pc – wt. 0,281 kg • 0,62 lb. pck. 6 pc • pal. 816 pc 8590992880930	30GC1396C MUG TASSE TASSE TAZA ЧАШКА ŠALEK Ø 82 mm • 4 3/8 in c. 410 ml • 13 3/8 oz h. 83 mm • 3 1/8 in l. – w. – h./11 pc – wt. 0,39 kg • 0,86 lb. pck. 6 pc • pal. 540 pc 8590992880992	30GC0033C BECHER GOBELET TAZON КРУЖКА HRNEK Ø 80 mm • 3 1/8 in c. 370 ml • 12 3/8 oz h. 106 mm • 4 1/8 in l. – w. – h./11 pc – wt. 0,31 kg • 0,69 lb. pck. 6 pc • pal. 672 pc 8590992881050	30GC0970C MUG BECHER GOBELET TAZON КРУЖКА HRNEK Ø 82 mm • 3 1/8 in c. 440 ml • 14 3/8 oz h. 128 mm • 5 in l. – w. – h./11 pc – wt. 0,37 kg • 0,82 lb. pck. 6 pc • pal. 432 pc 8590992881111
---	---	--	---

Saucers



30GC0227C SAUCER UNTERTASSE SOUCOUCPE PLATILLO БЛЮДЦЕ PODŠALEK Ø 120 mm • 4 3/8 in c. – h. 17 mm • 5/8 in l. – w. – h./11 pc 110 mm • 4 3/8 in wt. 0,13 kg • 0,29 lb. pck. 6 pc • pal. 3564 pc 8590992845854	30GC0238C SAUCER UNTERTASSE SOUCOUCPE PLATILLO БЛЮДЦЕ PODŠALEK Ø 170 mm • 6 9/16 in c. – h. 19 mm • 3/8 in l. – w. – h./11 pc 150 mm • 5 7/8 in wt. 0,275 kg • 0,61 lb. pck. 6 pc • pal. 1620 pc 8590992840569	30GC0234C SAUCER COMBO UNTERTASSE COMBI SOUCOUCPE COMBI PLATILLO COMBI БЛЮДЦЕ ЦОМБИ PODŠALEK COMBI Ø 155 mm • 6 1/8 in c. – h. 19 mm • 3/8 in l. – w. – h./11 pc 145 mm • 5 9/16 in wt. 0,25 kg • 0,55 lb. pck. 6 pc • pal. 2058 pc 8590992845977	30GC0268C SAUCER UNTERTASSE SOUCOUCPE PLATILLO БЛЮДЦЕ PODŠALEK Ø 195 mm • 7 5/8 in c. – h. 20 mm • 3/8 in l. – w. – h./11 pc 115 mm • 4 3/8 in wt. 0,315 kg • 0,7 lb. pck. 6 pc • pal. 1170 pc 8590992880633
--	--	---	--

SOLID COLOURS

colour	decoration number
dark green	G3006201
dark blue	G3006202
yellow	G3006203
brown	G3006204
black	G3006205
orange	G3006206
light green	G3006207
light blue	G3006208
red	G3006209

Cups	Saucers			
	120 mm	155 ml	170 ml	195 ml
80 ml	●			
100 ml	●			
160 ml		●		
240 ml		●		
350 ml			●	
410 ml				●
Mugs				
370 ml		●		
410 ml		●		

Ø = diameter · c. = capacity/contents · h. = height · in = inch · kg = kilogram · l. = length · lb. = pound · ml = milliliter
mm = millimeter · oz = ounce · pal. = pallet · pc = piece · pck. = pack · w. = width · wt. = weight

Capacities, weights and measurements are given as an indication only.

Decorations



CIRCLE LINE

G3003000



CIRCLE LINE

G3002900



CIRCLE LINE

G3003100



WORDS COFFEE

G2715500



WORDS CHOCOLATE

G2713700



SOLID COLOURS



Tovární 242
362 25 Nová Role
Czech Republic
Tel.: +(420) 353 410 800, +(420) 353 410 888
E-mail: sales@thun1794hr.cz
www.thun1794hr.cz

A Division of BOHEMIA CRYSTALEX TRADING a.s.

LE CAFE, T, CHOCOLATE



...serving professionals

Le Café, T, Chocolate



From espresso cup to chocolate mug – a variety of patterns, colours and shapes blends into a distinctive style
De la tasse à Espresso au gobelet à Chocolat – une variété de décors, de couleurs et de formes pour un style toujours reconnaissable

Von der Espressotasse bis zum Schokoladenbecher – Dekor, Farbe und Form sind variabel, der Stil bleibt unverwechselbar
Desde tazas para café expreso hasta tazones para chocolate – variedad de decoraciones, colores y formas, combinadas en estilo propio

От чашечки для «Эспрессо» до чашки для шоколада – разнообразие моделей, цветов и форм создают свой особый стиль
Od espresso šálků k hrnkům na čokoládu – různorodost dekorů, barev a tvarů sladěných do výrazného stylu

doplnit v textu čaj